

PART NUMBER	DESCRIPTION	OEM PART NUMBER
SP2510-00-10010	THERMAL SWITCH	352-0983-1
SP2510-00-1020	BREW CUP ASSEMBLY	665-0343-3, 11120-1
SP2510-00-2400	POT RETAINER	411-0716-1
SP2510-00-11004	BREW HEAD FITTING	3575-0189-01
SP2510-00-11015	ORIFICE	62-0066-1
SP2510-00-2630	STAND-OFF	352-0981-1
SP2510-00-2028	AERATOR	MISC-013
SP2510-00-2077	BUSHING, BREW HANDLE	411-0725-1
SP2510-00-2082	BUSHING, BREW HEAD	411-0692-1
SP2510-00-2097G	SENSOR SUBASSEMBLY	62-0075-3
SP2510-00-2105	PLUG	62-0010-1
SP2510-00-2153	THUMSCREW	62-0137-1
SP2510-00-3028	SWITCH (BREW/HW/CW)	SW50115, 513-1701-604
SP2510-00-3029	SWITCH (ON/OFF / WARMER)	SW50116, 513-1501-604
SP2510-00-5005	RELAY	KC-D4N-300L, RL-50035
SP2510-00-5070	RELAY SOCKET	RL-50017; RSE-112117
SP2510-00-6031	PLUNGER	62-0250-7
SP2510-00-7010	TANK	428-0074-1
SP2510-00-7014	VENT VALVE ASSEMBLY	3540-0001-01, 62-0135-1
SP2510-00-7016	PACKING, PREFORMED	OR-0941
SP2510-00-7017	BODY SUBASSEMBLY	62-0156-3
SP2510-00-7018B	BALL FLOAT	MISC-50187
SP2510-00-7019	HOUSING	3540-0001-03
SP2510-00-7030	THERMISTOR	55-0397-1, -3
SP2510-00-7031	WATER SENSOR	445-0910-5, -9, -11
SP2510-00-7050	HEATER, CM	440-0150-3, 3575-1251-07
SP2510-02-2022	TOUCH PANEL ASSEMBLY	3530-0035-1
SP2510-05-2575	HEATER RETAINER	3575-0549-01
SP2510-05-2590	HEATER	55-0392-1
SP2510-05-8160A	HEATER	440-0150-33
SP2510-08-12045	PLUNGER	3530-0279-09
SP2510-08-2265	FASTENER	3575-1215-01
SP2510-08-2310	FLOW WASHER	62-0066-7
SP2510-08-3105	VENT VALVE ASSEMBLY	3520-0594-01
SP2510-08-3120	LOW WATER SENSOR	MISC-50389
SP2514-05-1110	SERVER WARMER CAP	3575-0453-01
SP2514-05-1065	SPRING, LH	3530-0044-01
SP2514-05-1070	SPRING, RH	3530-0044-02
SP2514-05-1125	SWITCH	SW-50182, 510100
SP2514-05-1130	SWITCH, CAP	3530-0041-01
SP2570-00-4045	HEATER (CARTRIDGE STYLE)	11056-1
SP2570-00-4350	STEM	11069-3
SP2570-00-1855A	HEATER	55-0392-3
SP2570-00-3615	ORING	902-9-292
SP2570-00-5080	RTD DEVICE	11057-1
SP2570-00-5050	PRESSURE RELIEF VALVE	532T12MP95

PART NUMBER	DESCRIPTION	OEM PART NUMBER
SP2570-00-6080	FLOW RESTRICTOR	11172-1
SP2570-00-7070	1PDT MAINT SWITCH	31-281025
SP2570-00-7080	1PDT MOMENT SWITCH	31-151025
SP2570-00-7090	2PDT MAINTAIN SWITCH	31-282025
SP2570-00-8290	SOLID STATE RELAY	12322-1
SP2511-11-4059	KEYBOARD	(7S)236254
SP2511-00-2146	PT100 SENSOR	611498
SP2511-00-4036	HEATER, OVEN	(7S) 611132
SP2511-12-11109	PT100 SENSOR	CS257-02
SP2521-10-1165	FRAME ASSY, FRONT	8201-01-1050
SP2521-10-2005	PANEL, OUTER	8101-01-5321
SP2521-10-4030	TIMER, OCM	601LK8, TA4112
SP2511-13-2030	TIMER	2530-0041-01
SP3810-00-1020	ORING	20106-011
SP3810-00-1025	ORING	20106-012
SP3810-01-2005	DRAIN BUTTON	67490
SP3810-01-2015	DRAIN SHAFT	68217-1
SP3810-01-2010	COMPRESSION SPRING (SML)	67565
SP3810-01-1005	SURGE REDUCER	68080
SP3810-01-1053	GROMMET	31466
SP3810-01-2017	BALL, PLUNGER	31461
SP3810-01-4005	RED BUTTON ASSEMBLY	68108-1
SP3810-01-4017	TIMER, HYDRAULIC	31460-5
SP3810-01-4023	RED BUTTON	67496-1
SP3810-01-4028	BLUE BUTTON ASSEMBLY	68108-2
SP3810-01-4034	BLUE BUTTON	67496-2
SP3810-01-4035	CARTRIDGE	67839
SP3810-01-4038	CARTRIDGE	67839-3
SP3810-01-4074	GASKET	67566
SP3810-05-1070	ACTUATOR, LH/RH	68688-2, 68688-1
SP3810-05-1100	CARTRIDGE, FAUCET	67500-3
SP3810-07-1075	DIFFUSER ASSY	600399
SP3810-07-1080	GASKET	600444
SP3810-09-1065A	U-CUP SEAL	32802-1
SP3810-09-1035	AERATOR	32178-7
SP3810-09-1090	COMPRESSION SPRING (BUTTON)	31592
SP3816-14-1010	KNOB	9320-005
SP3816-14-1080	SPRING	501135
SP3816-14-1240	SHAFT, GEAR	501119
SP3816-14-1260	PLATE, MOUNTING	502663-1
SP3816-14-1280	SPRING	501129
SP3816-14-1290	SNUBBER PIN	501127
SP3816-14-1370	KNOB, UNLATCH	502608
SP3822-03-1015	LEVER ARM ASSEMBLY	7800116-006
SP3822-03-1080	FLOAT ASSEMBLY	7600160
SP3824-00-5010	RETURN TO SEAT PANEL	C23102-497-055

PART NUMBER	DESCRIPTION	OEM PART NUMBER
SP3824-00-5475	RETURN TO SEAT PANEL	C23102-497-051
SP3824-00-5492	RETURN TO SEAT PANEL	C23102-497-053
SP3824-00-5650	FLUSH SWITCH ASSEMBLY	C23102-275-001
SP3824-00-5660	MICROSWITCH ASSEMBLY	C23102-293-001
SP3824-00-5696	RUB PLATE	C23102-299-101
SP3824-00-5698	PLATE	C23102-291-101
SP3832-02-1285	SLIDE VALVE SEAL	15800-246
SP3832-02-2025	PLATE, MOUNTING	14330-190-2
SP3832-02-2255	MOUNTING PLATE	BP9
SP3832-02-3040	FACE SEAL	14330-086
SP3832-02-3055	SHAFT	14330-236
SP3832-02-3060	SLIDE PLATE	14330-235
SP3832-02-3120	POSITIONING PLATE GEAR	14330-070
SP3832-02-3130	GEAR ASSEMBLY	14330-073
SP3832-02-3250	BRACKET	15801-019
SP3832-02-3255	BRACKET	14330-241
SP3832-02-4056	POPPET	15800-357-2
SP3832-02-4250	SEAT	15800-349-2, -359-2
SP3834-03-7A420	FLUSH SWITCH ASSEMBLY	D72D93007-111
SP3834-03-7650	FLUSH SWITCH ASSEMBLY	D72D93002-111
SP3843-00-1170	HEATER, CARTRIDGE	24D507239P01
SP3877-00-1009	ACTUATOR, LEAF SPRING	001-9035-001
SP5610-01-1215	CORNER FITTING	69-36753-5
SP5610-01-1216	CORNER FITTING	69-36753-6
SP5610-02-1305L	LH #3 SEAL	5-71763-23
SP5610-02-1305R	RH #3 SEAL	5-71763-24